




GRID LEFT / RIGHT CHAISE UNIT TEAK

ASSEMBLY GUIDE



DISTRIBUTED IN THE USA BY:

Gloster Furniture
1075 Fulp Industrial Road
PO Box 738
South Boston
VA 24592
USA



DISTRIBUTED IN EUROPE AND ROW BY:

Gloster Furniture GmbH
Zeppelinsrasse 22
21337 Luneburg
Germany
Tel. +49 (0)4131 287530

GENERAL SAFETY GUIDELINES

Read this guide carefully before using the product.
Keep this guide for future reference, do not throw away.
Only use the product in accordance with these instructions. Failure to follow the instructions contained
Within the user guide can result in damage to the product, and the warranty will become void.
Any responsibility is disclaimed due incorrect use of the product.
This product is suitable for use in both residential and contract environments.

Warranty
www.gloster.com






GRID PLATFORM

206 CM X 26 CM

FRAME + CERAMIC TOP

ASSEMBLY GUIDE



DISTRIBUTED IN THE USA BY:

Gloster Furniture
 1075 Fulp Industrial Road
 PO Box 738
 South Boston
 VA 24592
 USA

DISTRIBUTED IN EUROPE AND ROW BY:



Gloster Furniture GmbH
 Zeppelinstrasse 22
 21337 Luneburg
 Germany
 Tel. +49 (0)4131 287530

GENERAL SAFETY GUIDELINES

IMPORTANT, RETAIN FOR FUTURE REFERENCE: READ CAREFULLY


Keep this guide for future reference, do not throw away.
 This product is suitable for use in both residential and contract environments.

Warranty
www.gloster.com



GRID COVER

ASSEMBLY GUIDE



DISTRIBUTED IN THE USA BY:

Gloster Furniture
1075 Fulp Industrial Road
PO Box 738
South Boston
VA 24592
USA

DISTRIBUTED IN EUROPE AND ROW BY:

Gloster Furniture GmbH
Zeppelinsrasse 22
21337 Lüneburg
Germany
Tel. +49 (0)4131 287530

GENERAL SAFETY GUIDELINES

Read this guide carefully before using the product.
Keep this guide for future reference, do not throw away.
Only use the product in accordance with these instructions. Failure to follow the instructions contained
Within the user guide can result in damage to the product, and the warranty will become void.
Any responsibility is disclaimed due incorrect use of the product.

Warranty
www.gloster.com

