

# SWAY TEAK LOUNGE CHAIR



WIDTH	79.5cm / 31.5"
DEPTH	73cm / 29"
HEIGHT	78cm / 30.5"
SEAT HEIGHT	45cm / 18"
ARM HEIGHT	60cm / 24"
PRODUCT WEIGHT	8kg / 17lb
CBM / CCF	0.72m <sup>3</sup> / 25.35ft <sup>3</sup>
DESIGNER	Henrik Pedersen
ASSEMBLY	Not Required

ITEM NUMBERS
108301 : Java Frame / Sepia Sling
103656 : Meteor Frame / Granite Sling
105179 : Meteor Frame / Anthracite Sling
103663 : White Frame / Seagull Sling

**MATERIALS**  
Natural finish teak & powder coated aluminium & stainless steel frame. Sling seat & back.

**ACCESSORIES**  
107065 : Protective Cover  
107484 : Seat Pad Cushion (Outdoor Performance Fabrics)  
107485 : Seat Pad Cushion (Water Resistant Fabrics)

**WARRANTY / MAINTENANCE**  
See [gloster.com](http://gloster.com) for warranty terms & maintenance instructions.

FRAME / SLING COLOUR

FRAME / SLING COLOUR

FRAME / SLING COLOUR

TEAK FINISH

