

CARE & MAINTENANCE FACT SHEET



OUTDOOR ROPE

Material Properties

Gloster outdoor rope is made from a vinyl coated, high strength polyester yarn, braided into a round rope profile of approximately 4mm diameter.

Cleaning

We recommend that outdoor rope products are cleaned using Gloster's Sling & Woven Cleaner, following the instructions detailed on the label. It is important to use a non-foaming cleaner, as a foaming product will leave residues in the gaps in-between the weave which will then attract dirt.

Gloster Sling & Woven Cleaner - 25oz / 750ml plastic bottle with trigger-action head. Water-based formula - both non-toxic and environmentally friendly. Cleans and restores the new look of sling and synthetic wicker woven furniture. Special non-foaming formula. Each bottle is supplied complete with a special applicator pad.

Instructions for Use

1. Before using the Sling/Woven Cleaner, protective gloves (included in box) and eye protection should be worn. Cover the ground under your working area before cleaning.
2. Shake Sling/Woven Cleaner before use.
3. Apply Sling/Woven Cleaner with a soft cloth or sponge. Allow to soak for 1 minute.
4. Brush the furniture clean with a soft scrubbing pad (included in box) and water.
5. Rinse furniture well with clean water.
6. Severely stained surfaces may require a second treatment.



SLING & WOVEN CLEANER